




Coupling (Coples)

**Coupling
(Coples)**Description
(Descripción)Dimensions
(Dimensiones)Part No.
(No. de parte)**Coupling 1 R-25
(Cople 1 R-25)**

L		D	
mm	inch	mm	inch
mm	pulg	mm	pulg
160	6 1/4	36	1 3/8

S302-0036**Coupling
(Coples)**Description
(Descripción)Dimensions
(Dimensiones)Part No.
(No. de parte)**Coupling 1 1/4 R-32
(Cople 1 1/4 R-32)**

L		D	
mm	inch	mm	inch
mm	pulg	mm	pulg
150	5 7/8	44	1 3/4

S303-0044**Coupling
(Coples)**Description
(Descripción)Dimensions
(Dimensiones)Part No.
(No. de parte)**Coupling 1 1/2 R-38
(Cople 1 1/2 R-38)**

L		D	
mm	inch	mm	inch
mm	pulg	mm	pulg
170	6 5/8	55	2 1/8

S304-0055



T38 Equipment (Equipo T38)


Coupling (Coples)

Description
(Descripción)

Dimensions
(Dimensiones)

Part No.
(No. de parte)

Coupling 1 ½ T38
Cople 1 ½ T38



L		D	
mm	inch	mm	inch
mm	pulg	mm	pulg
190	7 1/8	55	2 1/8

S335-0055


Coupling (Coples)

Description
(Descripción)

Dimensions
(Dimensiones)

Part No.
(No. de parte)

Coupling 1 ¾ T45
(Cople 1 ¾ T-45)



L		D	
mm	inch	mm	inch
mm	pulg	mm	pulg
150	5 7/8	63	2 1/2

S303-0044

Description
(Descripción)


Dimensions
(Dimensiones)

Part No.
(No. de parte)

Coupling Adapter
(Cople Adaptador)

Thread
(Rosca)

L		D	
mm	inch	mm	inch
mm	pulg	mm	pulg



R25-R32
R32-R38
R32-T38
R38-T38
T38-T45

160	6 3/8	44	1 3/4
170	6 3/4	55	2 1/8
170	6 3/4	55	2 1/8
180	7 3/8	55	2 1/8
180	7 3/8	60	2 1/8

S302-1044
S303-1055
S303-1155
S304-1055
S335-1060